

# User Guide

## IQSocket IQSW-IP10

Version v.0 rev0



Important information .....	3
<b>1 Introduction .....</b>	<b>4</b>
1.1 Product features .....	5
<b>2 Installation.....</b>	<b>6</b>
2.1 Wiring the IQsocket IQSW-IP10 .....	6
2.2 Powering IQSW-IP10 On.....	7
<b>3 Managing IQSW-IP10 .....</b>	<b>8</b>
3.1 Setting IP addresses .....	8
3.2 Managing by web browser .....	8
3.2.1 Status page .....	9
3.2.2 Network configuration.....	10
3.2.3 Test rules – watchdog function.....	13
3.2.4 Utility .....	17
3.2.5 Control socket .....	19
3.2.6 Logging .....	22
3.2.7 Quick setup.....	23
3.2.8 Automatic correction of parameter values.....	24
3.3 SNMP.....	25
3.3.1 Example - using SNMP under OS Windows.....	26
3.3.2 Example - using SNMP under OS Linux.....	28
3.3.3 SNMP trap example .....	28
3.4 Status data in XML format .....	29
3.5 IQLocator utility .....	29
<b>4 Indicators.....</b>	<b>32</b>
<b>5 Output socket wiring diagram .....</b>	<b>33</b>
<b>6 Reset to factory default using push button .....</b>	<b>33</b>
<b>7 Technical specification .....</b>	<b>34</b>
7.1 Operation, maintenance and safety recommendations .....	35
<b>8 Ordering and accessories .....</b>	<b>36</b>

## Important information

Every effort has been taken to ensure the accuracy of this document, however we do not accept responsibility for damage, injury, loss or expense resulting from errors and omissions, and we reserve the right of amendment without further notice.

**WARNING:** This product is not designed for use in, and should not be used for, medical applications.


The product doesn't guarantee safe power source disconnection, only functional switching of power is performed.

The product contains no serviceable parts, or internal adjustments. No attempt must be made to repair this product. Faulty units must be returned to supplier for repair. Improper use, disassembling or product modification causes warranty loss.

## 1 Introduction

IQsocket IQSW-IP10 is a member of family of intelligent power sockets brought to you by IQtronic, Ltd.

IQsocket IQSW-IP10 allows you to control of any electric appliance connected to the device's socket remotely over any IP network, including internet. You can use for this purpose any device supporting internet browser (HTTP protocol) such as PC, smartphone etc) or using SNMP protocol.



Besides controlling of the socket via IP protocol, IQsocket IQSW-IP10 is equipped with a choice of useful functions, including:

- Push button for manual control of the socket
- Watch dog function based on evaluation of ICMP packet loss
- Time scheduler function, allowing switching on/off your appliance based on day of week and time.

## 1.1 Product features

In general, IQsocket IQSW-IP10 has following features:


- Controlling (turn on, turn off; restart by cutting power for short time) of any electric appliance connected to the switched socket by HTTP and SNMP protocols or manually by pressing pushbutton on IQSW-IP10 body
- Configuring IQSW-IP10 parameters by HTTP or SNMP protocols, password protected
- XML and HTML status page, can be excluded from password protection, for easier integration with your web applications
- Can send SNMP traps
- IQLocator configuration utility allowing to autodiscovery your IQsocket devices within LAN network, setup IP address and upgrade firmware
- Automatic control based on evaluation of ICMP packet loss with up to three independent rules – watchdog function
- Automatic control based on day of week and time – scheduler function
- Real time clock synchronized using NTP protocol
- On board temperature sensor to monitor internal temperature
- Support remote firmware upgrade
- Event log storing up to last 50 events, such as socket on/off changes, device startups, LAN port connectivity, firmware upgrade etc.
- Tiny footprint firmware is efficiently coded in C/assembly, there is no Linux or other operating system inside, so startup times are really short (<3sec) and tcpip stack is clean with no hidden bugs ;-)

## 2 Installation

Before starting installation, please read this manual and take into account Important information section at beginning of this manual.

### 2.1 Wiring the IQsocket IQSW-IP10

Wiring is intuitive, simply wire RJ-45 jack into your Ethernet network using supplied cable, then connect your electric appliance to the device's socket and plug the IQSW-IP10 into a free electric socket.



#### **Note...**

*Both the socket and the plug of the IQSW-IP10 follow the same international standard and nominal voltage rating. Ensure you ordered proper international version of the IQSW-IP10 suitable for your country*



#### **WARNING!**

*Please respect maximum current rating of switched socket - 16A for resistive load. Do not overload your IQSW-IP10, as this may damage or shorten life span of the internal switching relay, which is not covered by warranty. It is recommended to use external contactor in case of higher current is required and/or capacitive/inductive load will be used.*

## 2.2 Powering IQSW-IP10 On

Once you plug your IQsocket IQSW-IP10 into a live electric socket, it become powered on and starts operation.

You can verify it by observing status of the LEDs:

- Once AC power is connected, all three LED indicators will blink shortly and internal self-test is performed. Then, if everything is ok, the Power LED (Red) will blink every second.
- LINK/ACT (Green) – solid light indicated established Ethernet link, blanked for short time when an Ethernet activity occurs
- The Output LED (Yellow) indicates state of output socket. Solid light means socket is active – appliance plugged into the output socket is operating and vice versa.

Please see chapter 3.5 for more information on LED indicators.

Your IQSW-IP10 is now ready for use.

### 3 Managing IQSW-IP10

This chapter guides you through management and configuration of IQSW-IP10.

Your IQsocket IQSW-IP10 is equipped with an internal web server, which provides an easy to use, intuitive and convenient way of management. You can both set up configuration and operation parameters and get information about device's status. There is also support for SNMP protocol, allowing to integrate your IQSW-IP10 into any SNMP management suite.

In order to access the web interface, it is necessary to setup IP network address on your PC properly.

#### 3.1 Setting IP addresses

Default IP address of the IQsocket IQSW-IP10 is 192.168.0.100, network mask 255.255.255.0.

In order to access your IQSW-IP10, it is necessary to setup IP address of your computer, connected to the same Ethernet network as the IQSW-IP10 properly – in this case set the IP address of the network adapter to 192.168.11, mask 255.255.255.0.

You can also change the IP address of your IQSW-IP10 using IQLocator utility, see chapter 3.5 for more information.

#### 3.2 Managing by web browser

Once you have properly set IP address of your PC, open the address of your IQSW-IP10 (default 192.168.0.100) in your favorite internet browser:




If everything is ok, status page will be displayed.



### 3.2.1 Status page

Provides summary of device status:



System information	
Device name	IP SOCKET
Location	Location
System timeup	0days 0hrs 0mins
System time	0days 0hrs 0mins
Firmware version	1.0.0
MAC address	00:19:51:10:05:29
System temperature	23.8 °C

Last event	
Last event	NO RECORD
Socket status	Turned OFF

Rules status	
Active rules	0

© IQtronic Ltd. , [www.iqtronic.com](http://www.iqtronic.com)

Explanation of parameters:


Section *System information* provide basic status information, such as Device name and Location, info on time, firmware version, Ethernet MAC address and temperature reading of internal temperature sensor.


Section *Last event* provides date/time of last change of socket state and current socket state.

Section *Rules status* informs about currently active automatic rules evaluating ICMP packet loss to chosen hosts.

### 3.2.2 Network configuration

Here you can configure networking and security parameters:


**IQ SOCKET IQSW-IP10**



**Status**  
**Network configuration**  
**Test rules**  
**Utility**  
**Control socket**  
**Logging**  
**Quick setup**

**Device configuration**

IP address	192.168.0.100
Network netmask	255.255.255.0
Gateway	0.0.0.0
Primary DNS	0.0.0.0
Secondary DNS	0.0.0.0
Device name	IP SOCKET
Location	Location
NTP server	tik.cesnet.cz
Timezone	+1 hr
User name	
Login password	
Verify password	
Except	<input type="checkbox"/> status.xml <input type="checkbox"/> status.html
HTTP port	80
SNMP	<input checked="" type="checkbox"/>
SNMP community read	public
SNMP community write	public
TRAP IP address	0.0.0.0
Output control event	<input checked="" type="checkbox"/> Relay <input type="checkbox"/> Send TRAP For MIB INFO click here, please.
SNMP time for restart	1 seconds
Add log events	<input checked="" type="checkbox"/> Power UP <input checked="" type="checkbox"/> Ethernet LINK
Output socket after POWER UP	<input type="radio"/> OFF <input type="radio"/> ON <input checked="" type="radio"/> REM

Save

© IQtronic Ltd. , www.iqtronic.com

Explanation of parameters:

### IP address

You can setup IP networking parameters such as *IP address*, *Network mask*, *Default Gateway*, *DNS servers*; please ensure to enter proper values. Please note it is necessary to define a fixed IP address even if case you are using a DHCP environment.



#### **Note...**

*When your local network is using private addresses behind a NAT router and you would like to make your IQSW-IP10 accessible from the Internet, it is necessary to setup port mapping (forwarding, server rule) in your router for the IP address assigned to IQSW-IP10 and selected ports, e.g. port TCP 80 for accessing web interface.*

SOHO example: Your network contains a modem/router with NAT for internet access, having IP address 192.168.1.254. Simply find an unused IP address from the private network range it use (192.168.1.1-192.168.1.253) e.g. 192.168.1.200, double check it is not used e.g. by using Ping command from your PC:

```
C:\>ping 192.168.1.200
```

Pinging 192.168.1.200 with 32 bytes of data:

Request timed out.

Then assign the 192.168.1.200 to the IQSW-IP10 by either IQLocator utility or by web interface and use address of the router (192.168.1.254) in both Gateway and DNS fields.

### NTP setup

IQSW-IP10 can synchronize its clock from an *NTP* (Network Time Protocol) server, please don't forget also to define *time zone*. Please note NTP feature will work only if IQSW-IP10 will have access to the Internet.



#### **Note...**

*It is highly recommended define NTP properly and allow your IQSW-IP10 accessing the Internet; otherwise logging and scheduler feature can't work properly.*

### Password protection

You can change/define a login username and password for protecting access to web interface. It comes with no password by default.



#### **Note...**

*If you want to disable password protection, enter blank login password.*

You can also activate exception from password protection for pages *status.xml* and/or *status/html* – when exceptions are active, those pages will be then always available without password, which is useful for further processing of the status information e.g. by scripts.

### HTTP port

It is possible to change port for the web interface from default value 80 by entering new value to *HTTP port* field.

### SNMP

SNMP can be deactivated by unchecking the SNMP checkbox, it is active by default. You can change passwords for *SNMP read* and *write communities* (default value is "public"). When there is an output control event resulting from assessment of automatic packet loss rules – the watchdog feature; IQSW-IP10 can send SNMP trap messages to defined IP address besides operating the relay of the socket, simply check particular check boxes *Relay* and/or *Send TRAP*.

The *SNMP time for restart* defines how long is socket turned off when restart command is issued via SNMP.

### Add log events

You can select, which events to write into the event log: *Power UP* will write event at every device startup and time has been successfully synchronized from NTP server; *Ethernet LINK* will write event at every time when Ethernet link has been established.

### Output socket state after startup

You can choice which state will have output socket after device will be powered on: to be off, on, or to remember last state before device has been turned off/power has been lost.

### 3.2.3 Test rules – watchdog function

You can configure here automatic watch dog function based on assessment of ICMP packet lost to selected IP host:



**IQ SOCKET IQSW-IP10**

**IQtronic**

- Status
- Network configuration
- Test rules**
- Utility
- Control socket
- Logging
- Quick setup

#### Test rules settings

**Rule 1 enable** ☐

Destination IP address

Ping data (bytes)

Packet loss  %

Packet timeout  msec

**Rule 2 enable** ☐

Destination IP address

Ping data (bytes)

Packet loss  %

Packet timeout  msec

**Rule 3 enable** ☐

Destination domain

Ping data (bytes)

Packet loss  %

Packet timeout  msec

Interval for send test packet  seconds

Interval for next test  minutes

☐ Maximum consecutive restarts  times

Time for restart  seconds

Number of packets to evaluate

Rules evaluation ☒ OR ☐ AND

© IQtronic Ltd. , [www.iqtronic.com](http://www.iqtronic.com)

Basically, you can define up to three test rules, two with numerical IP address of evaluated host, third rule can be defined using host name, and it's IP address will be resolved via DNS. Each rule is sending periodically ICMP test packets to the host and when number of received ICMP replies is lower than allowed packet loss, rule will generate request for output control event, which

can lead to restart of the output socket, sending of SNMP trap or both, depending on configuration. Finally, output control event is performed using logical OR or logical AND operations over the results (output control event requests) of particular rules.

## Defining rules

Each rule can be enabled or disabled by checking the checkbox. Enter IP address (*Rule 1, Rule 2*) or host name in case of the *Rule 3*, then size of ICMP frames, maximum allowed *packet loss* in % and *Packet timeout* interval, time how long will device wait for answers from the host – ICMP answers coming later that the Packet timeout will be considered as lost.



### Note...

*If you set Packet timeout to 0 (zero) value, device will use the value of Interval for send test packet as the Packet timeout interval.*

## Rules evaluation

Interval for send test packet	<input type="text" value="1"/>	seconds
Interval for next test	<input type="text" value="5"/>	minutes
<input type="checkbox"/> Maximum consecutive restarts	<input type="text" value="3"/>	times
Time for restart	<input type="text" value="5"/>	seconds
Number of packets to evaluate	<input type="text" value="10"/>	
Rules evaluation	<input checked="" type="radio"/> OR <input type="radio"/> AND	

You can define periodicity of sending test ICMP packets by entering it into *Interval for send test packet* field with allowed range 2-20 seconds.

*Interval for next test* is time delay till testing will begin after device has been started up or a rule has been activated (packet loss to a host detected).

You can limit maximum number of consecutive restart attempts by setting *Maximum consecutive restarts* parameter to prevent continuous restarting e.g. if there is a serious problem preventing target host to be recovered back by a restart via power cycling.


*Restart socket hold time* determines time interval how long is cut power of the output socket during a restart attempt.

*Number of packets to evaluate* represents how many test packets is used for evaluation of packet loss.

*Rules evaluation* allows to choose when an output control event (restart and/or SNMP trap) will be performed – in case of selected OR, it will be performed when ANY from rules is positive; while AND require that ALL rules must be positive.

## Diagram of rules evaluation

All referenced values come from *Test rules settings* page. *Request* means testing ICMP packets sent to the target host; *response* means received ICMP answers from the target host.





### 3.2.4 Utility

This page gives you possibility to restore factory default configuration, reboot device, upgrade firmware and clear statistics data:



The screenshot shows the 'Utility' page of the IQtronic IQ Socket IQSW-IP10 web interface. The page has a red header with the IQtronic logo and the text 'IQ SOCKET IQSW-IP10'. On the left, there is a sidebar with a list of menu items: Status, Network configuration, Test rules, Utility (highlighted), Control socket, Logging, and Quick setup. The main content area is titled 'Utility' and contains four sections: 1. 'Restore default configuration' with a 'Set to default' button. 2. 'Reboot this device' with a 'Reboot' button. 3. 'Firmware Upload' with a file input field, an 'Upload' button, and a 'Procházet...' button. 4. 'Clear statistic data' with a 'Clear values' button. At the bottom right, there is a copyright notice: '© IQtronic Ltd. , www.iqtronic.com'.

#### Restoring default configuration

*Restore default configuration* will revert all settings to the factory default values. It is necessary to reboot the device in order to activate new values using *Reboot* button:

#### Reboot device !

The Device will now be rebooting. Please wait 10 seconds for automatic reload.

## Clearing statistics

*Clear statistic data* will erase all collected statistics data displayed in Status page.

**Values has ben cleared !**

All statistic data has been cleared!

## Firmware upgrade

Using Browse button select file containing new firmware and then click to *Upload*. *Upgrade process will take about 50 seconds, which is indicated by fast blinking of the Power LED (red) and following message will be displayed I case of success:*

**Uploading successful !**

The Device will now be reprogrammed using the uploaded firmware file. Please wait 60 seconds for this process to complete, after which you may access these web pages again.

In case of an error will be detected, following message will be displayed:

**Upload failed !**

Please wait 10 seconds for return to main menu.



### **Note...**

*You can also upgrade firmware using IQLocator utility, please see chapter 3.5 for more information.*




### **WARNING!**

*Do not remove power during a firmware upgrade process, as it can render your device inoperational!*

### 3.2.5 Control socket

Here you can control the output socket manually and schedule automatic actions based on date/time.



**IQ SOCKET IQSW-IP10**

Status

Network configuration

Test rules

Utility

**Control socket**

Logging

Quick setup

**Socket output : Turned OFF**

**Schedule output**

Tue, 06 Mar 1900 07:12:37 GMT

Timezone: +1 h

☐ Enable scheduler

SaveDelete

**Scheduler example:**

Mo,Th,9:00,On OR Sa,9:22,Off

**Manual control**

RESTART socket now for  seconds

TURN ON socket now

TURN OFF socket now

© IQtronic Ltd. , www.iqtronic.com

## Socket status

Top of the page contains status row displaying current status of the socket:



## Manual control

Simply click to the buttons to turn on, turn off and restart (change current state to opposite one temporary for given number of seconds).

## Scheduler

This feature allows you to schedule output socket status, up to 50 records are supported.

Scheduler function use date/time synchronized by NTP protocol, so your IQSW-IP10 must have access to the Internet (or to an NTP server located within your private network), see also chapter 3.2.2.

Each scheduler record defines target socket state at given time. It is allowed to manually control the socket while scheduler is active – each change is done only at particular time.

Each scheduler record is having following structure:

DOW,...DOW,HH:MM, action

Where:

- DOW means Day of week, coded as first two letters of English day names: Mo, Tu, We, Th, Fr, Sa, Su;
- HH:MM means time in form of hour:minute in 24h format;
- Action means target socket state – off, on.


## Example

Enter following rows:

Mo,Tu,We,Th,Fr,Sa,Su,20:00,Off by clicking to *Save* button

Mo,Tu,We,Th,Fr,Sa,Su,21:00,On by clicking to *Save* button

and then activate scheduler by clicking to checkbox *Enable scheduler*

The screenshot shows a web interface for a scheduler. It has a light orange background. At the top, there is a text area with a blue border containing two lines of text: "Mo, Tu, We, Th, Fr, Sa, Su, 20:00, Off" and "Mo, Tu, We, Th, Fr, Sa, Su, 21:00, On". Below the text area is a checkbox with a green checkmark and the label "Enable scheduler". Underneath the checkbox is a text input field and two buttons labeled "Save" and "Delete". At the bottom, there is a section titled "Scheduler example:" followed by the text "Mo,Th,9:00,On OR Sa,9:22,Off".

Mo, Tu, We, Th, Fr, Sa, Su, 20:00, Off  
Mo, Tu, We, Th, Fr, Sa, Su, 21:00, On

☒ Enable scheduler

**Scheduler example:**  
Mo,Th,9:00,On OR Sa,9:22,Off

So scheduler will every day at 20:00 turn the output socket off and turn it on daily at 21:00.

You can use any combination of days of week, such as:

Sa,Su, 20:00, Off

Sa,Su, 21:00, On

to control the socket during weekends.

If you want to delete particular scheduler row, simply enter copy of the row and click to *Delete* button; you can also enter a part of row and all similar rows will be deleted.

If you want to delete all scheduler records, enter text *ALL* and click to *Delete* button.

### 3.2.6 Logging

This page display events recorded in the event log:



Event log can contain up to 50 records, oldest records being rewritten when log is full.

Automatically are recorded socket change events and firmware upgrade, optionally Ethernet link status and device startups, which can be configured in Network configuration menu.

All events are time stamped when time has been successfully obtained from an NTP server, so your IQSW-IP10 must have access to the Internet (or to an NTP server located within your private network), see also chapter 3.2.2.

Events can be sorted by time, *ascending* or *descending*, or *normal* by recorded order, you can choice sorting by clicking to the *sort* button.

#### Explanation of event types

Upgraded new firmware	an upgrade firmware has been done
POWER UP 0	device has been turned on by applying power
POWER UP 1	device has been manually rebooted

Restart www.domain.com 100%	restart due to www.domain.com has been inaccessible, with ICMP packet loss 100%
DEVICE OVERHEAT	Overheat condition, allowed internal temperature is 50°C.
TURN ON by BUTTON	socket has been turned on by the push button
TURN OFF by BUTTON	socket has been turned off by the push button
TURN ON by SCHED	socket has been turned on by scheduler
TURN OFF by SCHED	socket has been turned off by scheduler

### 3.2.7 Quick setup

This page provides setting up of basic networking and ICMP packet loss test rule parameters of IQSW-IP10 in an easy way suitable to less experienced users.



The screenshot shows the 'Quick setup' page of the IQ Socket IQSW-IP10 web interface. The page has a red header with the IQ Socket logo and the text 'IQ SOCKET IQSW-IP10'. On the left, there is a sidebar with a list of menu items: Status, Network configuration, Test rules, Utility, Control socket, Logging, and Quick setup (which is highlighted). The main content area is titled 'Quick setup' and contains two sections: 'Network' and 'Test rule'. The 'Network' section has three input fields: 'IP address' (192.168.0.100), 'Network netmask' (255.255.255.0), and 'Gateway' (0.0.0.0). The 'Test rule' section has two radio buttons: 'Destination is IP address' (selected) and 'Destination is domain'. The 'Destination is IP address' section has an input field for '0.0.0.0'. The 'Destination is domain' section has input fields for 'www.domain.com', 'Primary DNS' (0.0.0.0), and 'Secondary DNS' (0.0.0.0). At the bottom of the form is a 'Save' button. The footer of the page contains the copyright notice '© IQtronic Ltd. , www.iqtronic.com'.

In case of settings entered are wrong or missing, user is informed about it the status row; settings then must be repeated until they are accepted, which is indicated by following message in the status row:

Changes has been saved!

New settings is then passed into Test rules and are activated.

Possible errors include:

Error: Gateway must be defined for this ip!

An IP address of destination host out of current IP network range has been entered, but Gateway setting is missing or it is wrong.

Error: Destination IP must be defined!

Destination host IP address is missing.

Error: Gateway must be defined for this domain!

Gateway setting is missing, it is always required for a host specified by domain name.

Error: Domain name server is not defined!

If target host is specified by domain name, it is necessary to define also a DNS server which will be used to resolve IP address of the host.

### 3.2.8 Automatic correction of parameter values

WEB configuration interface has implemented function to detect incorrect parameter range. In such an attempt to enter a wrong value, an error message will be displayed in status row, the original value of parameter will be reverted back and displayed with red background:

#### Device configuration

Error: Wrong address format!

IP address

192.168.0.100

Network netmask

255.255.255.0



### 3.3 SNMP

IQsocket IQSW-IP10 contains support for SNMPv1.0 protocol, which makes possible to integrate it into any SNMP management suite. Advantage is also very small volume of data traffic required for SNMP. You can both monitor status and statistics using the GET commands and control output socket by using the SET command.

SNMP MIB table:



**IQ SOCKET**
**IQSW-IP10**

**Status**  
**Network configuration**  
**Test rules**  
**Utility**  
**Control socket**  
**Logging**  
**Quick setup**

MIB information , SNMP VER. 1	
GET Output status	0.1.3.6.1.4.1.21287.16.1.0
SET Output	0.1.3.6.1.4.1.21287.16.1.0 ; STRING 0 or 1
GET System temperature	0.1.3.6.1.4.1.21287.16.2.0
GET Location	0.1.3.6.1.4.1.21287.16.3.0
GET Device name	0.1.3.6.1.4.1.21287.16.4.0
SET RESTART Output	0.1.3.6.1.4.1.21287.19.5.0 ; STRING 1
GET active rules	0.1.3.6.1.4.1.21287.16.6.0
GET TRAP events 1	0.1.3.6.1.4.1.21287.16.7.0
GET TRAP events 2	0.1.3.6.1.4.1.21287.16.8.0
GET TRAP events 3	0.1.3.6.1.4.1.21287.16.9.0
GET SOCKET events 1	0.1.3.6.1.4.1.21287.16.10.0
GET SOCKET events 2	0.1.3.6.1.4.1.21287.16.11.0
GET SOCKET events 3	0.1.3.6.1.4.1.21287.16.12.0
GET test packet length 1	0.1.3.6.1.4.1.21287.16.13.0
GET test packet length 2	0.1.3.6.1.4.1.21287.16.14.0
GET test packet length 3	0.1.3.6.1.4.1.21287.16.15.0
GET test TX packets 1	0.1.3.6.1.4.1.21287.16.16.0
GET test TX packets 2	0.1.3.6.1.4.1.21287.16.17.0
GET test TX packets 3	0.1.3.6.1.4.1.21287.16.18.0
GET test RX packets 1	0.1.3.6.1.4.1.21287.16.19.0
GET test RX packets 2	0.1.3.6.1.4.1.21287.16.20.0
GET test RX packets 3	0.1.3.6.1.4.1.21287.16.21.0
TRAP event	.1.3.6.1.4.1.21287 Specific 0 or 1

© IQtronic Ltd. , [www.iqtronic.com](http://www.iqtronic.com)

SNMP MIB table can be displayed at any time via WEB configuration interface by clicking to „For MIB INFO click here, please“ link in *Network configuration* page (see chapter 3.2.2, where you can enable/disable SNMP, setup SNMP-related settings such as SNMP read/write communities, the trap address and

also configuring output control event behavior of the automatic packet-loss evaluating watch dog function to either control output socked, and/or sending SNMP trap. SNMP feature is enabled by default.


### 3.3.1 Example - using SNMP under OS Windows

There is plenty of SNMP utilities available under Windows OS, for example *iReasoning MIB browser* ([www.ireasoning.com](http://www.ireasoning.com)) or *PRTG Network Monitor* ([www.paessler.com](http://www.paessler.com)).

After installation of software, let's run it and configure it to work with IQsocket IQSW-IP10:




Enter IP address of the IQSW-IP10 (default value 192.168.0.100) and click to Advanced:



Here we will set *Read* and *Write* communities, matching settings of the IQSW-IP10 (default values are „public“). Then we can read from device value of each settings from the MIB table:

Result Table		
Name/OID	Value	Type
.0.1.3.6.1.4.1.21287.16.1.0	1	OctetString
.0.1.3.6.1.4.1.21287.16.2.0	27.5	OctetString
.0.1.3.6.1.4.1.21287.16.3.0	Location	OctetString
.0.1.3.6.1.4.1.21287.16.4.0	IP SOCKET	OctetString
.0.1.3.6.1.4.1.21287.16.5.0	5	OctetString
.0.1.3.6.1.4.1.21287.16.6.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.7.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.8.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.9.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.10.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.11.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.12.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.13.0	64	OctetString
.0.1.3.6.1.4.1.21287.16.14.0	64	OctetString
.0.1.3.6.1.4.1.21287.16.15.0	64	OctetString
.0.1.3.6.1.4.1.21287.16.16.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.17.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.18.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.19.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.20.0	0	OctetString
.0.1.3.6.1.4.1.21287.16.21.0	0	OctetString

In order to control the output socket of the IQSW-IP10, use menu SET:



SNMP SET

OID: .0.1.3.6.1.4.1.21287.16.1.0


Data Type: OctetString

Value: 0

Ok Cancel

Value 0 means turn off; 1 means turn on.


After successful command execution, a confirmation message will be displayed:



### 3.3.2 Example - using SNMP under OS Linux

Thanks to extensive support of SNMP in Linux OS, we can directly use commands *snmpget* and *snmpset*:


Obtaining status of the output socket: (IQSW-IP10 is on IP 192.168.2.54 in this example:



```
root@klip:~  
[root@klip root]# snmpget -v1 -O v -c public 192.168.2.54 1.3.6.1.4.1.21287.16.1  
snmpget: 1
```

Returned value 1 means socket is turned on; 0 means turned off.

To control status of the output socket: (IQSW-IP10 is on IP 192.168.2.54 in this example:



```
root@klip:~  
[root@klip root]# snmpset -v1 -O v -c public 192.168.2.54 1.3.6.1.4.1.21287.16.5 integer 1  
snmpset: 1
```

In this example, we restarted appliance connected to the output socket – power has been cut for time defined in Network configuration page.

### 3.3.3 SNMP trap example

In order to test SNMP traps, you can use TRAP receiver integrated in the *iReasoning MIB browser*.

### 3.4 Status data in XML format

IQsocket IQSW-IP10 contains status page in XML format, it can be accessed at <IP-address>/status.xml.

You can select if this page will be protected by password or not by setting exceptions at Network configuration page, see chapter 3.2.2.


The status.xml page uses the following format:

```
<status>
  <devname>IP SOCKET      </devname>
  <location>Location</location>
  <systimeup>0days 0hrs 2mins </systimeup>
  <systime>0days 0hrs 2mins </systime>
  <fwver>1.0.0</fwver>
  <macaddr>00:19:51:10:05:29</macaddr>
  <systemp>27.1</systemp>
  <lastevent>0days 0hrs 2mins </lastevent>
  <socket>Turned ON</socket>
  <rules>0</rules>
  <ip1></ip1>
  <evt1></evt1>
  <evs1></evs1>
  <pl1></pl1>
  <pr1></pr1>
  <pt1></pt1>
  <st1></st1>
  <at1></at1>
  <ip2></ip2>
  <evt2></evt2>
  <evs2></evs2>
  <pl2></pl2>
  <pr2></pr2>
  <pt2></pt2>
  <st2></st2>
  <at2></at2>
  <ip3></ip3>
  <evt3></evt3>
  <evs3></evs3>
  <pl3></pl3>
  <pr3></pr3>
  <pt3></pt3>
  <st3></st3>
  <at3></at3>
</status>
```


### 3.5 IQLocator utility

Purpose of IQLocator.exe utility is to make easier and faster initial configuration by locating your IQSW-IP10 using autodiscover, to change IP address and upgrade device firmware.

Simply connect your IQSW-IP10 with your computer or local Ethernet network using supplied cable and run the IQLocator.exe. After clicking to Scan button, a list of found devices will be displayed:




In order to change device IP address, select particular device by clicking to the row and then click to button "SET IP addresses" button:




Once you enter new IP address and click to "Set" button, a confirmation message "IP address was successfully set" will be displayed and new SCAN process will be performed to locate your device with new IP address. This IP address setting is temporary, valid until next device start. To make change IP permanent, it is necessary to use WEB management (see chapter 3.2.2) to save changes permanently.

You can upgrade firmware similar way by clicking to "Upload firmware" button.



After browsing the target file containing new firmware and clicking to "Upload" button, a progress bar will be displayed. Green Link LED indicator will blink during upload process.



When upload is finished, a confirmation message "Successful" will appear and now it is necessary to wait about 30seconds till internal firmware rewrite procedure finishes, during which the Power LED (red) will blinking fast. Then an automatic reboot of device will be performed and device is ready for use now.




### **WARNING!**

*Do not remove power during a firmware upgrade process, as it can render your device inoperational!*

## 4 Indicators

The IQsocket IQSW-IP10 is equipped with three LED indicators:



### **POWER**

BLINKS RED 1x PER SECOND  
BLINKS RED FAST

Input power and operation OK  
Firmware upgrade in progress, do not remove power!

### **LINK/ACT**

LIGHTS GREEN  
BLINKING

Link to Ethernet network established  
Ethernet activity in progress


### **OUTPUT**

NOT ACTIVE  
LIGHTS YELLOW

Output socket is OFF  
Output socket is ON



## 5 Output socket wiring diagram



Device uses a single pole relay switch, so it is not performing safe power disconnection of the appliance plugged into socket, only functional switching is performed.

## 6 Reset to factory default using push button

Each device come from factory preconfigured with factory default values. Device can be anytime returned back to these default values by using reset to factory defaults procedure.

Besides using web management, reset can be also done by the push button located near to the RJ-45 socket.

In order to restore factory default configuration, push the button for at least 5 seconds and then release. All LED indicators should start blinking for next 10 seconds. Please press the button again within these 10 seconds to confirm reset to factory default procedure. After this step is your device in original factory configuration.



### **WARNING!**

*Please BE CAREFULL! This step will erase all settings of your IQsocket IQSW-IP10.*

## 7 Technical specification

<b>Model</b>	IQsocket IQSW-IP10-E, CEE 7/5 French type socket IQsocket IQSW-IP10-F, CEE 7/4 "Schuko" earthed IQsocket IQSW-IP10-N, NEMA 5-15 USA socket IQsocket IQSW-IP10-B British BS 1363
<b>Mains power</b>	100-230VAC / 50-60Hz, own consumption 3Watts
<b>Output socket load</b>	16A max (resistance load)
<b>Management</b>	HTTP web management interface SNMPv1.0 Manual control using push button
<b>Security</b>	Password for logging into web management interface SNMP read/write community passwords
<b>Indicators</b>	POWER: red LED Link: green LED RELAY: yellow LED
<b>Features</b>	Appliance control over any TCP/IP network Remote restart of appliances Automatic watchdog based on ICMP packet loss monitoring Scheduler
<b>Dimensions</b>	(LxWxH) 140 x 65 x 55mm(92mm w/ plug)
<b>Weight</b>	0.2kg netto
<b>Operating temperature</b>	0 to +50 °C
<b>Humidity</b>	Max. 80%, non-condensing
<b>Environment protection</b>	IP40, for normal environment
<b>Installation category</b>	Class II, overvoltage max. 2500V
<b>Compliance</b>	CE, FCC

## **7.1 Operation, maintenance and safety recommendations**


- Do not modify product in any way and do not operate product modified any way. Warranty is void when product was disassembled or modified in any way.
- Product is not fused; ensure it is installed in fused electric installation only.
- Product can be operated only indoor office/house environment. Do not expose it to humid, wet nor chemically aggressive environment.
- Product is not designed for industrial operation with aggressive environment.
- Don't expose product to vibrations, shaking or fall downs to avoid product damage.
- Load current 16A is valid for resistive load. If you need to switch a non-resistive or higher current load, use an external contactor rated for target load among the product. Switching a non-resistive load or higher than nominal rating currents can cause permanent damage of switching elements, which is not covered by warranty.
- **WARNING:** This product is not designed for use in, and should not be used for, medical applications.

## 8 Ordering and accessories

IQsocket product family uses following ordering code system:

**IQSx-y-z**

Example: IQSW-IP10-F



### Ordering code

Code	Description
IQSW-IP10-X	pls specify socket type in place of X